

## RoverLog 2\_3\_1 Quick Reference Card

### Logging QSOs

Keystroke	Shortcut
Fn	Play Keyer Message <n> or QSY to Band <n>
F12	Focus to Main Window Call Entry
Alt-Key-+/=	QSY Up
Alt-Key--	QSY Down
Alt-Key-a/A	Accept next WIP
Alt-Key-b/B	QSY Up/Down
Alt-Key-d/D	Delete Entry from Log
Alt-Key-e/E	Edit Entry from Log
Alt-Key-j/J	Move Rotor
Alt-Key-o/O	Change to Next Mode
Alt-Key-t/T	Cancel Edit
Alt-Key-w/W	Clear Entry
Alt-Key-z/Z	Pop Callsign Off Stack
Return	Log QSO or perform other default action
Spacebar	Toggle between Call and Recd fields

### Keyer

Keystroke	Shortcut
Fn	Play Keyer Message <n> or QSY to Band <n>
Page Down	Decrease CW Speed
Page Up	Increase CW Speed
Alt-Key-<n>	Play Keyer Message <n>
Escape	Stop Keyer
Alt-Key-i/I	Key Transmitter via RoverLog Keyer
Alt-Key-y/Y	Popup Keyer

### Sub-windows

Keystroke	Shortcut
Control-F<n>	Net Message to Peer <n>
Alt-Key-F4	Hide Current Sub-Window
Alt-Key-c/C	Popup Calculator
Alt-Key-f/F	Popup Station Info
Alt-Key-h/H	Show Shortcut Help
Alt-Key-k/K	Popup Skeds
Alt-Key-l/L	Lookup Partial/Buddies
Alt-Key-m/M	Popup Map (centered on Sent)
Alt-Key-n/N	Popup Net
Alt-Key-p/P	Popup Pass
Alt-Key-s/S	Popup Score
Alt-Key-x/X	Popup Map (centered on Recd)

### Other

Keystroke	Shortcut
Alt-Key-v/V	Save Settings
Alt-Key-[	Toggle to Previous Network Peer
Alt-Key-]	Toggle to Next Network Peer